

# **DMR74**

# **QUICK START GUIDE**

Media Receiver with Bluetooth® featuring a 7" Touch Screen Display

This Quick Start Guide gives you the basics to start using your DMR74. Please visit www.dualav.com


to download a complete owner's manual or call customer service at 1-866-382-5476 (Monday-Friday, 9AM-5PM EST).



Customer Service Toll Free: 1-866-382-5476

# Installation

Mounting Brackets Shown Are For Illustration Purposes (Not Included)




Typical Front-Load Mounting Method

#### Copyright and Trademark Notes

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Siri and Apple are registered trademarks owned by Apple Inc.

Google Assistant and Android are trademarks owned by Google LLC. Other trademarks and trade names are those of their respective owners.

#### Wiring Diagram - Inputs/Outputs



#### **Control Locations**



5. Reset

6. AUX

1. Press- Mode Change Press and hold -- Voice Activation

2. Tune/Track Up 7. USB

3. Volume/Power/Mute

4. Tune/Track Down

#### Main Menu

In the Menu mode, press the desired icon to enter the corresponding mode: Radio, BT Phone, USB, EQ,BT Audio, Aux In, Camera, Settings.



#### USB Operations

Insert USB device in the USB slot, and the unit will read the USB device.

1. Home 7. Track Up 2. File Search Voice Activation 3. Settings 9. Play/Pause

4. Folder Up 10. Screen Dimmer 5. Audio 11. Track Down

6. Folder Down



# **USB File Search Operation**

1.Press File Search icon to File Search sub menu, press Folder Up / Folder Down to select suitable folder. Folder Name will be displayed. If file(s) are stored in ROOT (not folder), it will display "ROOT". 2.Select files directly from the keypad, then press CONFIRM to play the file.

- 1. Folder Name / current track / total track number
- 2. Folder Up
- 3. Previous Menu
- 4. Confirmed
- 5. Folder Down

## Audio Operation

Press Sound Effect icon in the Settings menu to select EQ Presets, 2-Band Tone Control, Fader and Balance controls.



#### **General Operation**

Press the function icons to select the setup menu.



#### **Tuner Operation**

Select the Tuner icon from the Main Menu screen or press MODE until Tuner is selected.

- 1. Information Display
- 2. Current Mode Indicator
- 3. Tune Up
- 4. Stereo/Mono
- 5. AS/PS
- 6. Preset
- 7. Local/DX
- 8. Band
- 9. Tune Down

### Bluetooth Operation

#### **Bluetooth Microphone**

The microphone is built-in to the receiver.

#### **Pairing and Connecting**

Before using Bluetooth functions, you must pair your mobile phone to the DMR74 unit. The device name is "DMR74".

To ensure the best reception for pairing and re-connection, please make sure the mobile phone battery is fully charged before you begin.

- Try to perform pairing within a few minutes of the mobile phone being turned on.
- Once the unit has been paired with the mobile phone, the unit's model number, "DMR74", will be displayed on the mobile phone.
- To achieve the best performance, always keep the mobile phone within 10 feet · Always keep a clear path between the mobile phone and the unit. Never place a
- metal object or any other obstacle between the mobile phone and the unit. • Some mobile phones may have a "Power Saving Mode" option. PLEASE DO NOT
- use the power saving mode with the DMR74.
- · Before accepting or making a call, make sure your mobile phone's "Bluetooth function" is turned on.
- To ensure the best conversation quality/performance, stay within 3 feet (1 meter) of the unit's microphone when talking.

#### Dialing a Number

Press to display keypad and dial a number.

# Making and Ending a Call

Press \( \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \( \begin{align\*} \text{to connect a call, and press } \end{align\*} \) end a call.

## **Transferring Audio**

Press = to transfer audio between the head unit and mobile phone.

## **Streaming Audio**

Press It to play or pause the music.

Press ◄ to skip to the previous track. Press by to advance to the next track.





### Voice Activation Operation

Bluetooth should be paired between your smartphone and the receiver. Press the voice activation button ( ), and the receiver will switch into Bluetooth mode, This will activate Siri® or Google Assistant™ on your smartphone. You will need to manually switch back to the previous or desired mode once this operation is terminated.

# APP Operation

The Dual Smart App is the ultimate wireless remote control for your DMR74 receiver. You can download Dual Smart app from Apple App Store or Google Play Store and install it on your smartphone or tablet.

Please scan the following QR code to download Dual iPlug P1 App to your smart phone.



# Limited One Year\* Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state Dual Electronics Corp. Inc warrants this product to the original purchaser to be free from defects in material and

workmanship for a period of one year from the date of the original purchase.

Dual Electronics Corp. Inc agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed, or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase

Subsequent replacement products are warranted for the balance of the original warranty period. What is covered? This warranty covers all defects in the material and workmanship in this product. The following are not covered: software, installation/removal costs, damage resulting from accident, misuse, abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair, or failure to follow instructions supplied with the product, or damage occurring during return shipment of the product. Specific license conditions and copyright notices for the software can be found via www.dualav.com.

# Warranty Coverage

\* Limited 1-year warranty. (Proof of purchase required)
Extend your warranty from 1 year to 2 years when you register online at www.dualav.com.

#### What to do?

1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any custom controls may save you a service call. 2. If you require service during the warranty period, you must carefully pack the product (preferably in the original

package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized 3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not

acceptable), and a daytime phone number with your shipment.

4. For more information and for the location of the nearest authorized service center please contact us by one of the following methods:

- Call us toll-free at (866) 382-5476
- (Monday-Friday, 9:00 am, to 5:00 pm, EST)

E-mail us at cs@dualav.com

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties, expressed or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental, or consequential damages.

# FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication

ver, there is no guarantee that interference will not occur in a particular installation. If this equipment does cau harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

©2024 Dual Electronics Corp